

Z

Zero Clearance Insert

A blank insert for a table saw, the blade is raised up through it to create a kerf close to the sides of the blade.

Zoning Laws

Laws adopted by local governments that restrict the location and type of new construction.